

Dynaflex Pipe IPS Size Loading Chart

IPS Size	SDR Range	Length	Sticks/Bundle	Bundles/Truck	Sticks/Truck	Feet/Truck
2"	7	50'	88	13	1144	57,200
2"	11-17	50'	88	14	1232	61,600
3"	5 - 7	50'	50	8	400	20,000
3"	7.3 - 9	50'	50	10	500	25,000
3"	11 - 17	50'	50	14	700	35,000
3"	21 - 32.5	50'	50	14	700	35,000
4"	5	50'	19	10	190	9,500
4"	6.3-7.3	50'	29	8	232	11,600
4"	9	50'	29	12	348	17,400
4"	11	50'	29	14	406	20,300
4"	13.5 - 32.5	50'	57	8	456	22,800
6"	7-7.3	50'	13	9	117	5,850
6"	9	50'	13	12	156	7,800
6"	11	50'	13	14	182	9,100
6"	13.5-32.5	50'	20	10	200	10,000

Dynaflex Pipe IPS Size Loading Chart

IPS Size	SDR Range	Length	Sticks/Bundle	Bundles/Truck	Sticks/Truck	Feet/Truck
8"	6.3-7.3	50'	9	8	72	3,600
8"	9	50'	9	10	90	4,500
8"	11-32.5	50'	14	8	112	5,600
10"	6.3-7.3	50'	4/5	9	45	2,250
10"	9	50'	4/5	12	54	2,700
10"	11-32.5	50'	4/5	16	72	3,600
12"	6.3-7.3	50'	4	8	32	1,600
12"	9	50'	4	10	40	2,000
12"	11	50'	4	12	48	2,400
12"	13.5-32.5	50'	4	14	56	2,800

Dynaflow Pipe IPS Size Loading Chart

IPS Size	SDR Range	Length	Sticks/Bundle	Bundle/Truck	Sticks/Truck	Feet/Truck
14"	7-7.3	50'	3/4	8	28	1,400
14"	9	50'	3/4	9	35	1,750
14"	11-32.5	50'	3/4	12	42	2,100
16"	7-7.3	50'	3	7	21	1,050
16"	9	50'	3	8	24	1,200
16"	11	50'	3	10	30	1,500
16"	13.5-32.5	50'	3	10	30	1,500
18"	7	50'	2/3	4	17	850
18"	7.3	50'	2/3	4	18	900
18"	9	50'	2/3	5	22	1,100
18"	11-32.5	50'	2/3	5	25	1,250